



File Name: Cz 527 User Manual.pdf

Size: 1638 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 5 May 2019, 12:36 PM

Rating: 4.6/5 from 637 votes.

Status: AVAILABLE

Last checked: 19 Minutes ago!

In order to read or download Cz 527 User Manual ebook, you need to create a FREE account.

[Download Now!](#)

eBook includes PDF, ePub and Kindle version

[❑ Register a free 1 month Trial Account.](#)

[❑ Download as many books as you like \(Personal use\)](#)

[❑ Cancel the membership at any time if not satisfied.](#)

[❑ Join Over 80000 Happy Readers](#)

Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with Cz 527 User Manual . To get started finding Cz 527 User Manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



Book Descriptions:

Cz 527 User Manual

Improper and careless handling of the firearm could result in unintentional discharge and could cause injury, death or damage to property. The same consequences can be caused by any unauthorized modifications or adjustments, corrosion, or use of nonstandard or damaged ammunition. In these cases the manufacturer shall not be responsible in any manner whatsoever for the resultant consequences. Before leaving the factory this firearm was tested, carefully inspected, and packed. CZ cannot accept responsibility for product handling while in transit, or upon leaving the factory. Therefore, please examine this firearm carefully at the time of purchase to ensure that it is unloaded and undamaged. This instruction manual should always accompany the firearm and that even in the case of its loan or sale. CONTENTS SAFETY INSTRUCTIONS 18 THE CZ 527 RIFLE DESCRIPTION AND TERMINOLOGY 20 OPERATING INSTRUCTIONS 22 Ammunition 22 Magazine Removal 22 Magazine Loading 22 Loading of the Rifle 22 Unloading of the Rifle 23 The Safety and its Operation 23 Settrigger Operation 23 Trigger Adjustment 23 Sight Adjustment 24 Rifle Scope 24 MAINTENANCE INSTRUCTIONS 24 Stripping for Cleaning Disassembly 24 Disassembly of the Bolt 25 Cleaning of the Rifle 25 Cleaning the Barrel Bore and the Cartridge Chamber 25 Cleaning of Other Rifle Parts 26 Preserving 26 Waste Management 26 LIST OF PARTS 27 TROUBLESHOOTING, CAUSES AND REMEDIES 28 TECHNICAL SPECIFICATIONS 29 LIST OF ILLUSTRATIONS 30 17 3 SAFETY INSTRUCTIONS Always follow the safety instructions for your safety and the safety of others. 1. Always handle your firearm as if it were loaded. 2. Never point your firearm at anything you do not intend to shoot. 3. Never take anyones word that a gun is unloaded. 4. Always make sure that your firearm is not loaded before laying it down, or handing it to another person. 5. Always store your rifle unloaded with the striking mechanism released.

6. <http://clarencetbrown.com/userfiles/craftsman-trim-saw-manual.xml>

- **cz 527 owners manual, cz 527 american owners manual, cz 527 user manual, cz 527 user manual pdf, cz 527 user manual download, cz 527 user manual free, cz 527 user manual instructions.**

Never abuse your firearm by using it for any purpose other than shooting. 7. Never leave a loaded firearm unattended. 8. Prior to loading the firearm make sure that barrel bore, chamber, and action are clean and clear of obstructions. Clean a dirtied firearm immediately so that it will function properly and safely. 9. Always use only clean, dry, original high quality commercially manufactured ammunition, which is appropriate to the caliber of your firearm. 10. Never drink alcoholic beverages or take drugs before or during shooting. 11. Always wear safety glasses and ear protection during shooting whenever possible. 12. Always keep the safety on when the rifle is loaded with a cartridge in the chamber, until you are ready to fire. Keep firearm pointed in a safe direction when disengaging the safety. 13. A rifle with an activated settrigger should be handed with maximum care, as even jolts during handling operations could cause an unintended discharge. 14. Always keep clear and keep others clear of the ejection port. 18 4 15. Never squeeze the trigger or put your finger in the trigger guard until you are aiming at a target and ready to shoot. 16. Always be absolutely sure of your target, and the area behind it, before you squeeze the trigger. If a hangfire slow ignition has occurred, the cartridge will fire within 30 seconds. If the cartridge does not fire, eject the cartridge and examine it. If something like this happens let the firearm to be examined and tested by a competent gunsmith. 19 5 THE CZ 527 RIFLE DESCRIPTION AND TERMINOLOGY The names of basic rifle parts used in this Instruction Manual are presented in Fig. 1 on the inner side of the cover. Nomenclatures of all CZ 527 parts are presented in the section List of Parts. The CZ 527

is a light repeating rifle with a Mauser type bolt action. The trigger mechanism is of a single set design with an adjustable set trigger; a single stage trigger is supplied on special order. <http://www.hamerwitgoed.com/userfiles/ducati-st2-service-manual.xml>

The trigger is adjustable for pull weight and trigger travel. The safety secures the rifle against unintentional discharge and at the same time blocks the bolt in a closed position. The top of the receiver has milled grooves to accommodate scope mounts. The stock surface is made in a semimatte polyurethane lacquered finish. The rifle is produced in several versions. Characteristic features of all versions are the CZ 527 is well balanced and consequently quick and easy to aim easy mounting of rifle scope controlling elements, which are simple in operation, and easy to reach bolt handle, trigger, safety, bolt catch, magazine catch completely adjustable trigger mechanism, alternatives with set trigger or without set trigger easy disassembly for cleaning and routine maintenance, which can be carried out without any tools a high degree of accuracy when firing and long service life high functional reliability in all environments, even with ammunitions made by various manufacturers, and with different types of bullets 20 6 Model Description Lux Exclusive FS American Prestige Carbine Varmint Hunter, Royal Classic walnut stock provided with a cheekpiece. This model is designed for aiming with mechanical sights as well as optical sights. Luxury version with stock made from highly figured walnut wood with a cheekpiece complete with contrasting ebony capped foreend and pistol grip. The metal parts surface is lustre polished, the bolt is jewelled. This model is produced with floating barrel. Full stock with cheekpiece and shortened barrel and rubber buttplate. Walnut stock without cheekpiece and with reduced drop at heel. This model is designed for aiming with optical sights only. This model is produced with floating barrel. Luxury version adapted to the requirements of markets in the USA and Australia. This model stems from version denominated American, additionally the stock is made from handpicked walnut wood.

The metal parts surface is lustre polished, the bolt is jewelled. Rifle made in shorter barrel version with a classic walnut stock without a cheekpiece. This model is designed for aiming with mechanical sights as well as optical sights. Full stock without cheekpiece, with reduced drop at heel and strengthened foreend. The barrel is of heavier type, floating, without mechanical sights, the stock is designed for aiming with optical sights only. Varmint USA is supplied with laminated or plastic stock. The stock made of Turkish walnut Hunter or American walnut Royal having cheekpiece of a new shape with reduced drop and wide forearm. Free floating barrel without sights. Stock is designated especially for sport shooting with riflescope. 21 7 OPERATING INSTRUCTIONS Ammunition Use only factory manufactured ammunition of appropriate caliber, which are in compliance with CIP regulations International Proof Commission for Firearms or SAAMI Sporting Arms and Ammunition Manufacturers Institute Inc. The use of other cartridges could damage the firearm or cause injury to the shooter. Magazine Removal Using one finger press the magazine catch towards the magazine Fig. 2, and with the remaining fingers grip the magazine bottom, and remove the magazine from the rifle. Magazine Loading With the open end uppermost, grasp the magazine in one hand. Place a cartridge on the magazine follower with the base just forward of the retaining lips. Press the cartridge down and back until its base touches the rear flat edge of the magazine. Place the next cartridge on top of the previous cartridge and slide in as already described. Loading of the Rifle ALWAYS MAKE SURE THE RIFLE IS POINTED IN A SAFE DIRECTION WHEN LOADING. Insert a loaded magazine into the rifle and check that it is securely caught by the magazine catch. Grip the rifle with the left hand by its foreend, place the buttplate against your body, and grip the bolt handle with the other hand.

<https://www.airyachtnboat.com/en/article/einhell-1840-manual>

Open the bolt by raising the bolt handle and pulling it to the rear to its stop. Then push the bolt continuously to its forward position again and by rotating the bolt handle in a downward direction close the bolt action. This procedure inserts the cartridge into the cartridge chamber and cocks the

striker mechanism. The rifle is now ready to fire. If you do not intend to fire immediately, ensure the firearm safety as described further in the section Safety and its Operation. 22 8 Note Loading is also possible for single cartridges by directly inserting into the chamber without the use of a magazine. This move puts the trigger mechanism out of operation, and at the same time blocks the bolt so that it is neither possible to fire the rifle or manipulate the bolt. Settrigger Operation The settrigger is activated by pushing it in the forward Fig. 4. For the reason of safety, activate the settrigger only after the rifle is loaded and shortly before shooting. Do not carry your rifle with an activated settrigger. If you have activated the settrigger and you do not follow through with firing, keep your firearm pointed in a safe direction while carefully engaging the safety and then squeeze the trigger. Subsequently unload the rifle in the manner described above. Trigger Adjustment Independent of whether there is a mounted settrigger or not, the trigger mechanism can be adjusted with respect to the trigger pull weight, and the trigger travel, before and after discharge Fig. 5. The adjustment can be performed after taking the barreled action out of the stock by means of the setting screws A trigger pull, B trigger travel before and C trigger travel after discharge. 23 9 If the CZ 527 rifle is fitted with a settrigger, the adjustment of the settrigger is carried out by the screw located in front of the trigger Fig. 6.

<http://artcustomdrums.com/images/canon-sx100-user-manual.pdf>

For safety reasons do not adjust the settrigger travel as too short, as the rifle with an activated settrigger is very sensitive to shock, and during handling the rifle could unintentionally discharge. The spontaneous release of the trigger must not occur. Note There is a possibility of dismantling the settrigger from the rifle, without any impairment to the functional properties or adjustment of the conventional trigger. Sight Adjustment The elevation correction is carried out by exchange of the front sight, when previously pressing the front sight detent Fig. 7. The front sights are supplied in different sizes. Windage correction can be carried out by the drifting of the rear sight in the dovetail and then secured in its position by an indentation. Rifle Scope Mounting of the riflescope and sightingin of the rifle should be entrusted to a qualified gunsmiths workshop. If you want to dismantle the firing pin spring, press the firing pin spring retainer against the spring pressure approx. 2 mm, and then rotate in any direction by 90 and remove from the firing pin together with spring Fig. 10. Please note carefully the correlated positioning of parts, especially of the bolt body and the bolt body sleeve. After each disassembly and reassembly of the bolt, check for yourself if it is possible to engage the safety in the manner described in this Instruction Manual. CAUTION Do not strip your firearm any further. If you assume that your firearm requires adjustment or repair, entrust this work to a competent gunsmith in a specialized workshop.

<https://gruposolux.com/images/canon-sx100-is-user-manual.pdf>

Cleaning of the Rifle Clean the rifle Each time you use it If you get your rifle wet As soon as possible after shooting At least once a year in a temperate climate As often as once a month in a tropical climate, or other demanding environment Cleaning the Barrel Bore and the Cartridge Chamber If the firearm has not been fired or if only a few cartridges have been fired, clean the barrel bore and cartridge chamber by a clean patch attached to a cleaning rod. Repeat, changing patches, until the last patch comes out clean. When the barrel bore is very dirty, apply a gun cleaning solution using a cleaning brush. Let the solvent act for about 10 minutes this time may vary depending on the solvent agent being used. Then thoroughly scrub out the barrel bore. Subsequently, dry the barrel bore and cartridge chamber with a clean patch and check that all powder residues or fouling have been removed. If necessary repeat this procedure. 25 11 The cleaning rod and the brush must be inserted into the barrel bore from the chamber, to prevent wear or damage to the muzzle. Pass the brush all the way through the barrel bore before reversing the movement. If you try to change directions with the brush in the barrel, the brush could stick. Cleaning of Other Rifle Parts Other parts of the rifle can be cleaned with a dry cloth, old toothbrush, copper bristle brush or a wooden scraper.

Preserving oil or paraffin oil can be used for proper cleaning. Never use the agent designed for barrel bore cleaning. These solutions could remain in the joints, and after some time could cause corrosion. Check that cloth particles or brush bristles have not become lodged in any part of the rifle. The maintenance of the stock can be carried out with a dry cloth or by some furniture polishing product. Preserving When the barrel bore, cartridge chamber, and all accessible parts are clean and dry, wipe these parts with a cloth soaked in gun oil or apply the oil in a spray. Remove all excess oil.

Before shooting always wipe the barrel bore dry. At very low temperatures remove the oil from all accessible parts or apply a lubricant prepared especially for these conditions. Use thick preserving agents for example, preserving grease only for longterm storage in demanding climate environments, and before any use of the rifle it must be thoroughly removed from all parts of the firearm. Waste Management When used properly, the materials used in the product and packaging have no adverse effects on human health or the environment. However, if such a situation does occur please observe the following instructions. CAUTION if a malfunction occurs, the possibility of an unintentional discharge is substantially increased. For this reason, when clearing malfunctions, observe the Safety Instructions already mentioned above. Keep the rifle pointed in a safe direction, do not turn the rifle against your body or anyone else's. Do not place your hands in front of the barrel. The spent case has not been ejected. Magazine is not fully inserted or is damaged. The rifle or cartridges are fouled dirty. Defective cartridge. Firing Pin hole fouled dirty or improper lubrication agent used during low temperature conditions. The primer has been activated but no powder load was inside the cartridge case. Cartridge chamber, extractor or ammunition dirty or unsuitable lubricant in low temperature environment. Insert magazine properly or change magazine. Clean the rifle and cartridges and wipe them dry or as the case may be slightly lubricate. Follow the Safety Instructions according to point 20. Disassemble and clean the firing pin or use low temperature lubricant. Unload the rifle and check that the bullet is not lodged in the barrel. Any subsequent shot could cause damage to the barrel. Clean and wipe the rifle dry or eventually lubricate lightly with a suitable agent. Use clean and new ammunition.

Disassembly of the firing pin spring The Company, reserves the right to make any changes it thinks necessary to improve its models or to meet any requirements of manufacturing or commercial nature. 30 16 17 18 Improper and careless handling of the firearm could result in unintentional Improper and careless handling of the firearm could result in unintentional If rifle is not cocked, selector lever cannot be pointed toward safe. If rifle is not cocked, selector lever cannot be pointed toward safe. 2. Point rifle in a SAFE DIRECTION!! 3. Remove magazine by pressing magazine catch With proper care and handling, it will give you many years of long, reliable It is vital to your safety and to the safety of others that you accurately follow the information contained Accidental discharge of weapon Made in America For best performance we suggest that you use American Handling and Safety Instructions USA Disregarding information Manuel d instruction. Manual de instrucciones. Break barrel air pistol Patent Pending Keep this manual with your pistol and review it before Failure to follow the safety rules and other Read the instructions and warnings in this manual CAREFULLY Keep this manual with your firearm and review it before Register this product The Green Dot is designed as the primary targeting The CQB Series of Scopes give you many great options so you can choose the scope that best fits your needs. Backed by Though the translation has been checked for accuracy, no claim of 100% accuracy is implied. The stock is formed ergonomically and available as real right We work around the clock and around the globe to ensure that our products maintain The highquality finish of the complete rifle Failure to follow the safety rules and other basic DO NOT DESTROY It is the customer's responsibility to have all operators and service personnel read and understand this manual.

Failure to follow the safety rules and other basic safety precautions may result in serious UPC CODE 065857161175 Espresso 065857161168 Pine NOTE Lot number Date of purchase Underlever action.

A scope only Karbine air rifle. Fixed barrel precision, WARNING This is not a toy. I was asked to send Medcop a description of how Repair Information. W Series Geroler Motors Series FULLY SHROUDED BARREL AT4410 Tact QE More Power Even though velocity rates may appear the same from brand Failure to follow the safety rules and other basic safety The information contained As the first Speed Connect The Cimarron MultiPitch Pitching Machine is a high performance pitching machine To use this website, you must agree to our Privacy Policy, including cookie policy. Improper and careless handling of the firearm could result in unintentional discharge and could cause injury, death, or In these cases the manufacturer shall not be responsible in Before leaving the factory this firearm was tested, carefully inspected, and packed. CZ cannot accept responsibility for Therefore, please examine this rifle carefully at the time of This instruction manual should always accompany the firearm and that even in the case of its loan or sale. Disassembly of the Bolt. Cleaning the Rifle. Cleaning the Barrel Bore Cleaning of Other Rifle Parts Magazine Removal. Magazine Loading. Loading of the Rifle. Unloading of the Rifle. The Safety and its Operation. Settrigger Operation. Trigger Adjustment. Sight Adjustment. Rifle Scope. Preserving A bullet could travel If a hangfire slow ignition has occurred, the round will fire within 30 seconds. If the If something like this happens, let the firearm to be examined and The CZ 527 is a light repeating rifle with a Mausertype bolt action. The trigger mechanism is of a single set design with The trigger is adjustable for pull weight and The stock surface is made in a semi The rifle is produced in several versions. Characteristic features of all versions are Lux.

<http://dev.pb-adcon.de/node/21078>